

NEW – Reusable o-ring insulator plugs for Mallory 9000 series Pro Cap adapter ring screw holes. Replaces the need for silicone! Utilizes - 902 o-rings.

Be sure adapter ring counterbores are free of old cured silicone. Use a small amount of silicone grease on the o-rings before insertion. Push in until plug contacts the screw head. A small portion of the plug should remain above to allow access to the side hole. Use a pointed tool in the side hole to quickly remove the plug when required.

After installation, install rotor and check for clearance with the top of the plug.

NEW – Reusable o-ring insulator plugs for Mallory 9000 series Pro Cap adapter ring screw holes. Replaces the need for silicone! Utilizes - 902 o-rings.

Be sure adapter ring counterbores are free of old cured silicone. Use a small amount of silicone grease on the o-rings before insertion. Push in until plug contacts the screw head. A small portion of the plug should remain above to allow access to the side hole. Use a pointed tool in the side hole to quickly remove the plug when required.

After installation, install rotor and check for clearance with the top of the plug.

